EG800 Series

Version: v1.0

Date: **14.04.2025**





Contents

1	Copyright Regulatory Compliances 2.1 CE and UKCA Notice				
2					
3	afety Instructions				
4	Product Specifications 4.1 Technical Details	5			
5	Power Supply				
	Interfaces and Connections 6.1 Front I/O	10 10			



1 Copyright

Copyright and Trademarks, 2025 Publishing. All Rights Reserved

This manual, software and firmware described in it are copyrighted by their respective owners and protected under the laws of the Universal Copyright Convention. You may not reproduce, transmit, transcribe, store in a retrieval system, or translate into any language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, biological, molecular, manual, or otherwise, any part of this publication without the express written permission of the publisher.

All products and trade names described within are mentioned for identification purpose only. No affiliation with or endorsement of the manufacturer is made or implied. Product names and brands appearing in this manual are registered trademarks of their respective companies. The information published herein has been checked for accuracy as of publishing time. No representation or warranties regarding the fitness of this document for any use are made or implied by the publisher.

We reserve the right to revise this document or make changes to any product, including circuits and/or software described herein, at any time without notice and without obligation to notify any person of such revision or change. These changes are intended to improve design and/or performance.

We assume no responsibility or liability for the use of the described product(s). This document conveys no license or title under any patent, copyright, or mask work rights to these products and makes no representations or warranties that these products are free from patent, copyright, or mask work right infringement, unless otherwise specified.

Applications described in this manual are for illustration purposes only. We make no representation or guarantee that such applications will be suitable for the specified use without further testing or modification.



2 Regulatory Compliances

2.1 CE and UKCA Notice

This device complies with the requirements of the CE directive and UKCA regulations.

Low Voltage Directive 2014/35/EU + Electrical Equipment Safety Regulations 2016 (SI 2016 No 1101)

- EN IEC 62368-1:2020+A11:2020
- BS EN IEC 62368-1:2020+A11:2020

EMC Directive 2014/30/EU + Electromagnetic Compatibility Regulations 2016

- EN 55032:2015+A11:2020
- BS EN 55032:2015+A11:2020
- EN 55032:2015+A11:2020
- BS EN 55032:2015+A11:2020
- EN IEC 61000-3-2:2019
- BS EN IEC 61000-3-2:2019+A1:2021
- EN 61000-3-3:2013+A1:2019
- BS EN 61000-3-3:2013+A1:2019+A2:2021
- EN 55035:2017+A11:2020
- BS EN 55035:2017+A11:2020
- EN 61000-4-2:2009
- BS EN 61000-4-2:2009
- EN 55035:2017+A11:2020
- BS EN 55035:2017+A11:2020
- EN 61000-4-3:2009
- BS EN 61000-4-3:2009
- EN 61000-4-3:2006+A1:2008+A2:2010
- BS EN IEC 61000-4-3:2020
- EN 61000-4-4:2012
- BS EN 61000-4-4:2012
- EN 61000-4-5:2014+A1:2017
- BS EN 61000-4-5:2014+A1:2017
- EN 61000-4-6:2014
- BS EN 61000-4-6:2014
- EN 61000-4-8:2010
- BS EN 61000-4-8:2010
- EN 61000-4-11:2004



• BS EN 61000-4-11:2004

RoHS 2 Directive 2011/65/EU & 2015/863/EU + RoHS 2 Directive 2020 No. 1647

- Exemption(s) used:
- 6c,7a,7c-l



2.2 FCC PART 15 VERIFICATION STATEMENT

WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

2.3 ICED-003 ISSUE 7 VERIFICATION STATEMENT

CAN ICES3(B)/NMB3(B)

This device complies with CAN ICES-003 Issue 7 Class B. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



3 Safety Instructions

Please read these instructions carefully and retain them for future reference.

- 1. Disconnect this equipment from the power outlet before cleaning. Do not use liquid or sprayed detergent for cleaning. Use a moist cloth or sheet.
- 2. Keep this equipment away from humidity.
- 3. Ensure the power cord is positioned to prevent tripping hazards and do not place anything on top of it.
- 4. Pay attention to all cautions and warnings on the equipment.
- 5. If the equipment is not used for an extended period, disconnect it from the main power to avoid damage from transient over-voltage.
- 6. Prolonged usage with less than 8V may damage the PSU or destroy the mainboard.
- 7. Never pour any liquid into openings as this could cause fire or electrical shock.
- 8. Have the equipment checked by service personnel if:
 - The power cord or plug is damaged.
 - Liquid has penetrated the equipment.
 - The equipment has been exposed to moisture in a condensation environment.
 - The equipment does not function properly, or you cannot get it to work by following the user manual.
 - The equipment has been dropped and damaged.
- 9. Do not leave this equipment in an unconditioned environment, with storage temperatures below -20 degrees or above 60 degrees Celsius for extended periods, as this may damage the equipment.
- Unplug the power cord when performing any service or adding optional kits.
- 11. Lithium Battery Caution:
 - Risk of explosion if the battery is replaced incorrectly. Replace only with the original or an equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.
 - Do not remove the cover, and ensure no user-serviceable components are inside. Take the unit to a service center for service and repair.

Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

☑ Caution!

Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.



4 Product Specifications



4.1 Technical Details


Fea- ture	Specifi- cation	Details
Pro- cessor	CPU	11th Gen Intel® Tiger Lake-UP3 Core™ i ULV Processor:• i3-1115G4E – Dual Core, 6MB Cache, up to 3.90 GHz• i5-1145G7E – Quad Core, 8MB Cache, up to 4.10 GHz• i7-1185G7E – Quad Core, 12MB Cache, up to 4.40 GHz
Secu- rity	I/O Chipset	Nuvoton NCT6126D
	TPM	Nuvoton NPCT750AABYX TPM 2.0
Mem- ory	System Memory	DDR4 3200 MHz, 1 × 260-pin SO-DIMM, up to 32GB (Non-ECC)
Graph- ics	GPU	Intel® Iris Xe Graphics
Dis- play	Display Inter- faces	HDMI, DisplayPort
Stor- age	Storage Slots	1 × Hot Swappable 2.5" HDD/SSD (max 9.5 mm height); 1 × M.2 B Key (2280/2260/2242)
Net- work- ing	Ethernet	Intel® I225-LM 2.5GbE LAN, Intel® I219-LM Giga LAN <i>(Optional: 2 × Intel® I210-IT Giga LAN,</i>
Audio	Audio	Realtek® ALC256
Expan- sion	Expan- sion Slots	Wireless: M.2 2230 E Key (PCIe, USB)Storage/LTE/5G: M.2 B Key (USB 2.0 / PCIe x1 / SATA III)Note: Does not support M.2 M Key NVMe SSD. 5G card support available as a BOM option.
Indica- tors	LED Indi- cators	Power LED, HDD LED
I/O Ports	Front I/O	3 × RS2321 × RS232/422/4851 × Audio Combo Jack (Mic-in/Line-out)1 × Hot Swappable 2.5" HDD/SSD slot2 × USB 2.02 × SMA Antenna (Optional)
	Rear I/O	2 × DisplayPort 1.22 × HDMI 1.42 × RJ-454 × USB 3.1 Gen 2 (10 Gbps)1 × 3-pin Termina Block Power Input1 × 2-pin Terminal Block Remote Power On/Off2 × SMA Antenna (Optional)
Watch- dog	Software Pro-	1–255 Steps
Timer	grammable	
Power	Power In- put	Alderamin Pico Mk4: 8–24V DC Input with Terminal Block ConnectivityNote: Power Ignition Expansion Module is optional for Pico Mk4-D.
Cool- ing	Thermal Design	Fanless
Me- chani- cal	Mounting	Wall Mount / Side Mount; Optional VESA Holes (75 mm × 75 mm) & DIN Rail Mount Kit
	Dimen- sions	8.3" × 5.9" × 2.5" (210 mm × 150 mm × 63 mm)
	Material	Top Cover: Aluminum Alloy; Bezel & Chassis: Steel
Envi- ron-	Oper- ating	15W TDP: -40°C to 70°C; 28W TDP: -40°C to 60°C (0.7 m/s airflow assumed)
	H Tempera-	www.welotec.com
um Hagenba 8366 Laer		info@welotec.com Pag
	Oper-	10% to 95% R/H (Non-condensing)





4.2 Dimensions

4.2.1 System Drawings











5 Power Supply




Use the terminal block to connect the Edge Gateway to a 8-24V DC power source.

Pin	Signal
1	DC IN +8~24VIN (EG800)
2	NC
3	GND



6 Interfaces and Connections

6.1 Front I/O



6.2 Rear I/O

